




COMPONENTS



- 1** Drill 10 mm hole for cable entry.




- 2** Fix Dtrack to ceiling.



800-1000 mm

- 3** Make electrical connection to feed adapter. Remove side knock-out.



48V / DC - polarity insensitive

