





POINTER TRACK

POINTER TRACK

4601.XX

POINTER TRACK

1. INSTALL THE BULB.
2. FIX THE ADAPTER TO THE TRACK.



DEKKO

12-16 DRAGAN TSANKOV BLVD
1164 SOFIA,
BULGARIA

T +359 (0)2 8168116
F +359 (0)2 8168118

office@dekkonet
www.dekkonet

