




OPTIC

OPTIC
OPTIC TRIMLESS

2028.XX
2018

OPTIC GU10

1. CUT-OUT THE REQUIRED MOUNTING APERTURE IN THE SUSPENDED CEILING.
2. MAKE THE ELECTRICAL CONNECTION.
3. FIX THE BODY TO THE CEILING.
4. PULL OUT THE FRONT REFLECTOR AND INSERT THE BULB.
5. REASSEMBLE THE REFLECTOR.




CUT-OUT:

1X1


2028

85x85 mm



OPTIC GU10 TRIMLESS

1. CUT-OUT THE REQUIRED RECESSING APERTURE AND SCREW THE FRAME TO THE SUSPENDED CEILING.
2. LEVEL THE FRAME SO IT IS FLUSH WITH THE CEILING SURFACE.
3. PLASTER THE GAP BETWEEN THE FRAME AND THE GYPSUM BOARD.
4. MAKE THE ELECTRICAL CONNECTION AND INSERT THE BODY INTO THE FRAME.
5. PULL OUT THE FRONT REFLECTOR AND INSERT THE BULB.
6. REASSEMBLE THE REFLECTOR.



CUT-OUT:
NOT ACCESSIBLE
CEILING


1X1

2018

100x85 mm

CUT-OUT:
ACCESSIBLE
CEILING

85x85 mm



DEKKO

12-16 DRAGAN TSANKOV BLVD
1164 SOFIA,
BULGARIA

T +359 (0)2 8168116
F +359 (0)2 8168118

office@dekkonet
www.dekkonet